

dB

- "dB" are a relative measure and can make sense only in relation to another level.
- Saying "the level of this signal is 5 dB" is similar to saying "the cost of this candy bar is 5 cents more."
- When judging the response of your filter(s), measure them in relation to a good reference level (e.g., near DC or pi); the absolute level does not matter.
 - Be careful if your input signal does not have a flat spectrum

B. Baas, © 2008 EEC 281, Winter 2008 185

dB

- Consider two signals: *x* and *y* and suppose *x* is 10x larger in magnitude than *y*
- $Power = voltage^2 / resistance$, so P_x is 100x larger than P_y
- "Normal" dB
 - $-20*\log_{10}(x/y)$
 - $-20*\log_{10}(10y/y) = 20*\log_{10}(10) = x \text{ is 20dB larger than } y$
- "Power" dB
 - $-10*log_{10}(P_x/P_y)$
 - $-10*\log_{10}(100 P_y/P_y) = 10*\log_{10}(100) = x \text{ is 20dB larger}$ than y

B. Baas, © 2008 EEC 281, Winter 2008